

Earth & Sky, Inc.

PO Box 235
White Hall, VA 22987

Phone 434-823-4600
Toll Free 877-353-7783
info@earthandskysolutions.com
www.earthandskysolutions.com

Model 4500 Lesche Bed Shaper Set up Guide.

The disks in the front are adjustable for the amount of soil you would like to hill up. The mounting brackets shown here have not been tightened.



The shaping boards in the front behind the disks, are adjustable for the width of the bed top you are trying to achieve. The lower the leading edge, the more soil it will capture. The higher the trailing edge, the wider the bed will be.

The pitch of the center leveling board will also determine the width of the bed.

The lower it is, the narrower the bed will be.



If the disks are worn and need to go deeper than the brackets allow, spacers can be placed between the disk mount angle iron with the vertical bolts and the disk to 3 point hitch angles (the ones that are adjustable from side to side).

The center leveling board is adjustable with the all threaded adjusters.



Front shaping board adjustment holes. In the center, at trailing edge.



Front shaping board adjustment holes. In the front, at leading edge.

